



# Acer Aspire One D250-1151 Battery Replacement

This guide shows how to safely remove the battery from the laptop.

Written By: Evan Edmunds



## INTRODUCTION

This guide will help the user locate and safely remove the battery.

## Step 1 — Battery



- ⚠ Make sure the computer is unplugged, and turned off completely
- Place the computer on a flat surface with the bottom facing you.

## Step 2



- Place a finger on the small tab on the left with the lock and unlock symbols.
- Slide this tab to the unlock position.
- ⓘ If done correctly, you should see an orange marker.



## Step 3



- Place a finger on the tab in the upper right corner.
- Slide this tab to the right and hold it in that position.

## Step 4



- Place your finger on the three lines in the middle of the battery while holding the tab on the right.

## Step 5



- Push forward on the battery lines while holding the tab on the right.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-17 03:20:11 PM.